
TORNUM Centriklon Dust Separator



High capacity in a compact format

TORNUM Centriklon has been designed to effectively separate solid particles from the air in grain treatment applications. Working by centrifugal force and inertia action, dust collection is highly efficient, leaving less than 50 mg/m³n particulate emissions in the processed air. The Centriklon can be included in any system where cyclones are used and is easy to install, thanks to very compact dimensions throughout its size range.


A reliable design – easy to install and maintain

- Robust, fully welded design with no moving parts in the separator ensures high operational reliability
- 6 different installation arrangements possible easy to fit in existing applications.
- Low maintenance one monthly inspection and cleaning is sufficient.
- · Easy access for cleaning on both sides.
- Inspection windows as standard.
- Excentric locking on secondary duct and draining cone for quick removal when servicing.
- Available in 7 sizes.





COLLECTING EFFICIENCY



The chart above is applicable at an inlet velocity of 18 m/s and a dust concentration of 5 g/m³. At a velocity of 12 m/s, use the next line on the right. The settling rate equivalent diameter of a particle is the diameter of a sphere with a density of 1 g/cm³ which, in air at 20 °C and 1013 bar (760 mm Hg), has the same falling velocity as the relevant particle.

WEIGHTS (kg) AND MEASUREMENTS (mm)

									Min. < Air flow > Max.			
Size	A	В	C	D	E	F	G	Weight	m³/s	m³/h	m³/s	m³/h
CDS 40	900	450	1620	570	1037	446	330	355	5,0	18000	6,7	24000
CDS 45	1000	500	1808	640	1167	532	375	435	6,1	22000	8,3	30000
CDS 50	1100	550	1991	720	1282	600	405	495	7,5	27000	10,0	36 000
CDS 55	1200	600	2179	810	1402	660	410	575	8,6	31000	12,5	45 000
CDS 60	1300	650	2370	910	1542	710	445	660	10,0	36000	14,4	52000
CDS 65	1400	700	2561	1010	1672	750	480	760	12,2	44 000	17,8	64 000
CDS 75	1600	800	2944	1260	1933	916	525	1180	15,3	55 000	23,6	85 000

